






Marquee Tent Instruction 6X6M 20'x20' w/sidewalls




Part No.	Description	Picture	Quantity
1	Eave Pole		8
2	Leg Pole		4
3	Center Pole 1		1
4	Center Pole 2		1
5	Flag Pole		1
6	Sleeve		4


7	Cross Cable		2
8	Corner Joint		4
9	Foot pad		4
10	Peg 1 700mm		4
11	Peg 2 1000mm		4
12	1' Ratchet Stape		4
13	2''Ratchet Stape		4
14	Roof		1

15	Sidewall		4


I: Lay all the parts on the ground as shown.




II: Put all the joints and poles together.




III: Install one cross cable.




IV: Lift the left corner and suspend another cable.




V: Assembly the roof cover, pull the corner with handle.



VI: Push the center pole upright.




VII: Insert all the legs to make the tent stand up.



Note: use pegs to fix the tent on the ground

VIII: Suspend all the sidewalls.



Note: use the buckles fix the sidewall on the frame

IX: Fasten the ratchet ropes and use the ratchet strapes make the tent more stable.

Marquee Tent Instruction 6X6M 20'x21' w/sidewalls

